

Install and Un-stall the Driver

1.Install

1).PC driver install

You can find 【0575_USB_Vibration_Joystick_V10.exe】 from the CD,double click to install, follow the tips to finish the installation as shown in following pictures:




2).PC360 driver install

Only below than WINDOWS7 system for your PC computer or notebook,and then you need to install the driver,if no install the driver,PC 360 will not use.

if above WINDOWS7 system,no need to install.

You can find the 【Xbox360_32chs.exe】 from the CD or Microsoft official website,double click to install, follow the tips to finish the installation as shown in following pictures:



2.Un-install

[0575_USB_Vibration_Joystick] is with self unload function.

Players can delete [0575_USB_Vibration_Joystick]all driver files,program package and shortcuts.

Click[STAR]-[CONTROL PANEL]-[ADD/DELETE]to open the 【USB_Vibration Joystick(BM)】 installer.Then un-install or delete the[0575_USB_Vibration_Joystick]quickly following the prompts.