

# ANT ESPORTS

## MK1200 Mini

MECHANICAL BACKLIT GAMING KEYBOARD

### WARRANTY

Ant Esports MK1200 MINI Mechanical Backlit Gaming Keyboard comes with 1 year warranty.

#### Warranty Card

Customer Name : \_\_\_\_\_  
 Product Name : \_\_\_\_\_ Model No.: \_\_\_\_\_  
 Address: \_\_\_\_\_ Date of Purchase: \_\_\_\_\_  
 Dealer Name : \_\_\_\_\_ Phone No.: \_\_\_\_\_

### CONNECT WITH US ON

**ANT ESPORTS**  
 www.antesports.com  
 support@antesports.com

\*Notice: Any alteration of the clauses and contents and copies are invalid.

# ANT ESPORTS

## MK1200 Mini

MECHANICAL BACKLIT GAMING KEYBOARD

## User Manual & Warranty Card



### TECHNICAL SPECIFICATIONS

<b>Keyboard Type</b>	: 60% Form Factor
<b>Connectivity</b>	: USB to Type-C
<b>Color</b>	: Black
<b>Layout</b>	: 61 English (Mini)
<b>Switch</b>	: Red Switches
<b>Keys Type</b>	: Full Ghosting Mechanical Keys
<b>Cable Type</b>	: Braided Cable
<b>Cable Length</b>	: 1.5m
<b>Working Voltage</b>	: 5V
<b>Working Current</b>	: <150mA
<b>Lifespan</b>	: 50 Million Clicks
<b>Weight</b>	: 390g
<b>Dimensions</b>	: 290*100*39mm

### IN THE BOX

Keyboard, User Manual

### KEYBOARD FUNCTIONS

COMBINATION KEY : FUNCTION	: DESCRIPTION
FN + ( })	: LED Brightness + : Brightness Adjust, 4 Brightness Levels
FN + ( {)	: LED Brightness - : Brightness Adjust, 4 Brightness Levels
FN + (")	: LED Speed + : LED Running Speed Adjust, 5 Different Speeds
FN + (:)	: LED Speed - : LED Running Speed Adjust, 4 Different Speeds
FN + (*)	: Switch LED Mode : In Total 17 Modes
FN + (Space Key)	: Rest : Long Press For 3 Sec To Rest
FN + (CTRL-L)	: Switch First Line Key Function : "ESC To ←" Switch To "DEL" "Y U I H J K N M, <" Switch To "Print Scr / Scroll Lock / Pause / Insert / Home / Page Up / DEL / End Page Down"
FN + (Enter-L)	: Switch Direction Keys : "↑↓→←" Switch To "; / ALT-R / APP CTRL-R"

### KEYBOARD FUNCTIONS

COMBINATION KEY	: FUNCTION	COMBINATION KEY	: FUNCTION
FN + (↑)	: /?	FN + ESC	: "
FN + (↓)	: APP	FN + (1)	: F1
FN + (←)	: ALT-R	FN + (2)	: F2
FN + (→)	: CTRL-R	FN + (3)	: F3
FN + (WIN-L)	: WIN Lock	FN + (4)	: F4
FN + (Y)	: Print Scr	FN + (5)	: F5
FN + (U)	: Scroll Lock	FN + (6)	: F6
FN + (I)	: Pause	FN + (7)	: F7
FN + (H)	: Insert	FN + (8)	: F8
FN + (J)	: Home	FN + (9)	: F9
FN + (K)	: Page Up	FN + (0)	: F10
FN + (N)	: DEL	FN + (+)	: F11
FN + (M)	: END	FN + (=)	: F12
FN + (,<)	: Page Down		
FN + (Backspace)	: DEL		
FN + (Shift-L+↑)	: /?		

### HOW TO USE

Type-C Plug into keyboard. USB plug into PC, it can be used!



### SAFETY INSTRUCTIONS

1. Keep the keyboard away from sharp object that could damage it.
2. Do not put heavy objects on the keyboard.
3. Do not put stretch, twist or apply force to the keyboard.
4. To clean the keyboard, gently wipe it using a moist cotton cloth.
5. Make sure the keyboard is turned off before cleaning. Do not use liquid cleanser.