

ANT ESPORTS
GP310R
WIRELESS GAMEPAD

Warranty

Ant Esports GP310R Wireless Gamepad Comes With 1 Year International Warranty.

Warranty Card

Customer Name : _____
Product Name : _____ Model No. : _____
Address : _____ Date of Purchase : _____
Dealer Name : _____ Phone No. : _____

CONNECT WITH US ON

ANT ESPORTS

www.antesports.com
support@antesports.com

*Notice: Any alteration of the clauses and contents and copies are invalid.
*All product names, logos, and brands are property of their respective owners.
All company, product and service names used here are for identification purposes only.
Use of these names, logos, and brands does not imply endorsement.



ANT ESPORTS


GP310R
WIRELESS GAMEPAD

Multifunction Game Controller

For PC X-Input & D-Input / Ps3 / Ps4 / Xbox360 / Android


USER MANUAL

● Key Instruction



● X-Input Mode

Defaultmode




1st Step. Press MODE to power on the controller, LED1,2,3,4 flashes waiting for matching.
2nd Step. Plug the receiver to USB port of the PC device.
3rd Step. Gamepad conected successfully to device with LED1.2.3 long on & 1s vibration feedback,

● D-Input Mode


Press the **MODE** button while under X-Input, the gamepad mode switch to D-Input Mode, the LED turn to LED3 and LED4.

● Android Controller Mode




1st Step. Press MODE to power on the controller, LED1,2,3,4 flashes waiting for matching.
2nd Step. Plug the receiver to USB port of the Android media box, android tv set.
3rd Step. Gamepad conected successfully to device with LED2 long on & 1s vibration feedback,

● Ps3 Controller Mode




1st Step. Press MODE to power on the controller, LED1,2,3,4 flashes waiting for matching.
2nd Step. Plug the receiver to USB port of the Ps3 gaming console.
3rd Step. Gamepad conected successfully to console with LED3 long on & 1s vibration feedback,

● PS4 Controller Mode




1st Step. Press MODE to power on the controller, LED1,2,3,4 flashes waiting for matching.
2nd Step. Plug the receiver to USB port of the P4 gaming console.
3rd Step. Gamepad conected successfully to receiver with LED3 long on & 1s vibration feedback, Press MODE button again to start gaming.

● Xbox360 Controller Mode



1st Step. Press MODE to power on the controller, LED1,2,3,4 flashes waiting for matching.
2nd Step. Plug the receiver to USB port of the Xbox360 Gaming console.
3rd Step. Gamepad conected successfully to device with LED1.2.3 long on & 1s vibration feedback,

● Turbo Function & Speed Adjustment



● Specifications

Product Name: Multifunction Gamepad
Model Number: GP-310R
Product Size: 152x115x58mm
Product Weight: 220g
Battery: 800mAh

● In The Box

Gamepad, Manual, Charging Cable